

Alexander J. Maclean, Peter W. Roth, David Burns, Alan J. Kemp*
 Institute of Photonics, University of Strathclyde, 106 Rottenrow, Glasgow, G4 0NW, Scotland. (*alan.kemp@strath.ac.uk)

Peter F. Moulton
 Q-Peak Inc., 135 South Road, Bedford, Massachusetts 01730, U.S.A.

Abstract: Pump wavelengths of less than 460nm compromise the performance of Ti:sapphire lasers by inducing loss. This – and not pump brightness or absorption – is the primary performance limitation for diode-laser pumped Ti:sapphire lasers.

Introduction: Importance of Ti:Sapphire

- Ti:sapphire [1] is the most widely used gain material in scientific lasers, unrivalled in terms of tuning (100s of nm) and ultra-short pulse generation (<10fs possible).
- Widely used in e.g. precision spectroscopy, ultrafast science and biological imaging.
- Costly and bulky blue-green pump lasers are typically required.
- Threshold typically large (~1W) – $\sigma\tau$ product is small: intrinsic losses are large.
- Small pump absorption coefficient puts a premium on pump brightness.
- Compact, low cost pumps would improve applicability to applications beyond the lab.




Fig.1: Comparison of a diode laser and a standard pump laser

CW and fs Diode-Pumped Ti:Sapphire Lasers

- Direct diode-laser pumping possible despite the wavelength mismatch (450nm; absorption peak 490nm) and reduced pump brightness (1W, $M^2 \sim 1.5 \times 6$).
- CW: 19mW output power for 1W diode-laser pump (fig. 2-4) [2].
- Modelocked: 9mW, 110fs transform-limited pulses for 1W diode-laser pump [3].
- A slow degradation of performance (minutes) until a steady-state is reached – the performance noted above is for the lower power steady state.




Fig.3: Schematic of diode-laser pumped Ti:Sapphire laser

Pump Induced Loss: Effect on Laser Performance

- Lower performance than expected even accounting for reduced pump source brightness and wavelength mismatch (c.f. modelling based on [4]).
- Over a few minutes of diode-laser pumping CW output power reduces from 60mW to a steady state level of 19mW (not observed for 532nm pumping).
- Performance stable at this level (19mW) even after being switched off overnight.
- Initial performance recovered by pumping at 532nm for some tens of minutes.
- The nature of this degradation explored in a co-pumping experiment (figs.5, 6):
 - Pumping at 476.5nm and 532nm – no degradation in output power (fig.6)
 - Pumping at 457.9nm and 532nm – expected increase in power when 457.9nm switched on but slow degradation to steady-state; expected decrease and then slow increase back to original level when 457.9nm light blocked again. (fig.6)
- No reduction in fluorescence observed – indicative of an increase in loss rather than a reduction in gain.




Fig.4: Diode-laser pumped Ti:Sapphire laser

Fig.5: Schematic of the co-pumping experiment




Fig.6: Output power as a function of time for co-pumping as per fig.5

Pump Induced Loss: Wavelength Dependence

- Pumping on the available Ar⁺ lines, a clear reduction in performance can be seen for 457.9nm compared to the other lines (fig. 7)
- This is also evident in the reduction in slope efficiency and increase in threshold (fig.8) – a clear difference between pumping at 457.9nm and 476.5nm and above.
- This is reflected in the intracavity losses (fig.9); for a pump wavelength of 457.9nm, the loss is ~1% higher than at 488nm or 532nm. (Discrepancy between Findlay-Clay and Caird approaches is commonly observed for vibronic lasers e.g. [5].)
- Similar effects reported by Hoffstädt [6] in flashlamp pumped Ti:sapphire lasers and tentatively ascribed to charge transfer interactions between Ti³⁺-Ti⁴⁺ pairs.
- A fit to the absorption profile of Ti:sapphire based on the Jahn-Teller splitting of the upper level of Ti³⁺ (fig.10) suggests that the low wavelength tail (460nm and below) of the absorption can not be explained by Ti³⁺ alone.
- It may be that a different centre or species is responsible for the induced loss. This is under investigation.




Fig.7: Output power as a function of absorbed pump power for pumping with a variety of Argon-ion lines




Fig.8: Threshold and slope efficiency as a function of pump wavelength under Ar⁺ pumping. Blue points show diode-laser pumping data

Conclusions:

- 19mW CW and 9mW in 110fs pulses demonstrated for 1W of diode-laser pump
- Shorter pump wavelengths (<458-477nm) induce additional loss, restricting performance
- Even so, CW output powers of ~100mW should be possible with double sided pumping
- The origin of the induced loss is not fully understood but appears to relate to absorption in a centre other than solely Ti³⁺
- Progress of GaN diode lasers to longer wavelengths may soon circumvent this problem

Fig.9: Round trip loss, measured using Findlay-Clay and Caird analyses, as a function of pump wavelength (458, 488nm – Ar⁺; 532nm – doubled Nd:YVO)

Fig.10: The absorption profile of Ti:sapphire with a fit accounting for the Jahn-Teller splitting of the upper level

References:
 1. Moulton, JOSIA B, 3, 125, 1986 2. Roth, OL, 34, 3334, 2009 3. Roth, submitted to CLEO 2010.
 4. Alfrey, JOE, 25, 760, 1989 5. Payne, JOE, 24, 2243, 1988 6. Hoffstädt, JOE, 33, 1850, 1997